


Prener-LC PREAMP USER'S MANUAL

Functions

4Band EQ & LCD Digital Processing Tuner



- | | |
|----------------------|--------------------------------------|
| 1. Tuner LED Display | 6. Presence |
| 2. Tuner LCD Display | 7. Note |
| 3. Bass | 8. Low Batt. (Low Battery LED Light) |
| 4. Middle | 9. Volume Knob |
| 5. Treble | 10. Power on/off Button |

— 1 —

3. Bass EQ TONE CONTROL (for bass tones)
4. Middle EQ TONE CONTROL (for middle tones)
5. Treble EQ TONE CONTROL (for high tones)
6. Presence EQ TONE CONTROL (for very high tones)

The BASS, MIDDLE, TREBLE, and PRESENCE controls are a 4-band equalizer for controlling tone. The BASS, TREBLE and PRESENCE tone controls are normal boost / cut shelving controls. The MIDDLE (midrange) tone control is a normal boost / cut tone filter. The center detent on these tone controls yields a flat tone response. "+12" boosts the tone; "-12" cuts the tone.

7. Note Button

8. Low Batt. (Low Battery LED Light)

The LED will light when the battery has lost power. Replace the battery when this light is on. This LED light will flash when a cable is connected to the output jack of the pickup system. This shows the battery is good.

9. Volume Knob

The VOLUME controls the output volume. Turned fully counter-clockwise it is completely OFF. Turned fully clockwise it is LOUD!

10. Power on/off Button

The tuner will work with or without a cable plugged into the output jack.



Battery

A 9-volt battery powers the PRENER-LC preamp. Before connecting the instrument to an amplifier or mixer please check that a fully charged 9-volt battery is connected.

— 2 —

Tuner Operation

Specification



Tuner Display

The tuner will work with or without a cable plugged into the output jack.

Pushing the tuner button turns ON the tuner. When the tuner is active the output signal is muted. No sound will go to the amplifier or mixer when the tuner is active.

Pushing the tuner button again turns the tuner OFF and the output signal will be active and sound will go to the amplifier.

If the tuner is ON and the tuner button is not pushed within 2 minutes the tuner will turn OFF automatically and sound returned to the output.

The tuner Note Readout Display shows the nearest note of one plucked string's sound. The Note Read Display read out shows twelve note possibilities in half steps in "sharps" (for example: A; A#; B; C; C#; D; D# and so on). For "flat" notes, for example: Bb (B flat) use A#. For Eb (E flat) use D#.

— 3 —

- Features :** 4Band EQ & LCD Tuner
Input Impedance : 2.2MΩ
Frequency Response : 20Hz~20KHz
Control Range :
 Bass : [±12dB at 60Hz]
 Middle : [±12dB at 500Hz]
 Treble : [±12dB at 3KHz]
 Presence : [±12dB at 10KHz]
Power Supply : 9V Alkaline Battery
Battery Life : Only EQ,
 Tuner off : Over 700Hours
 Tuner on with signal : Over 300Hours
Tuner Function :
 Mode : Auto & Manual Tuning Mode
 Tuning Note : Chromatic Mode / Guitar Mode
Function : LCD Tuner System
 Chromatic & Guitar or Bass tuning mode
 Balance & Unbalance Output Jack
Pick-up : Piezo ceramic pick-up
Battery Box : XLR Combo Battery Box
Dimension : W 58mm X H 98 mm (2.3" x 3.8")

Caution

- The jack should be plugged for proper Preamp working. (TUNER will works regardless plugging jack)
- There is no output sound, please check if tuner or mute is turned on.
- When LCD screen is dim or no display, please check battery life.
- To prevent battery loss, please unplug jack when preamp is not in use.
- Do not disassemble for repair. Return to your dealer for service or repair.
- Do not use too much force when operating the control.


Belcat®
 BELCAT Co.,Ltd.
 Tel: +86 752 355 7545
 Fax: +86 752 355 2460
 Email: belcat@belcat.com
 Internet: www.belcat.com




— 4 —

INSTALLATION MANUAL


1. Contents



1. Preamp



2. Battery Box



3. Pick-Up



4. Clip



5. Screw

2. Tool



1. Electric Drill



2. Drill Bit
(2.3mm or 3mm)



3. Phillips Screwdriver



4. Router and Grinder
(cutting-edge 3mm)





5. Round File




6. Masking Tape


1. Cut out the hole with template



2. Drilling hole for pick-up




3. Insert EQ and battery box into hole of guitar.
4. Fasten screws properly.




5. Put plugs into jacks.

7. Fix wire with clip.



6. Installing the pick-up



Solution

- 1) When there is no sound or sound is stopped,
 - Check guitar cable, amp or Mixer
 - Check if there is batter or not. When it happens noise or distortion, please exchange battery.
 - Check if the pickup and battery connector is connected correctly or not.
 - Check if out put jack is connected correctly.
- 2) When there is hum-noise,
 - Check the pickup is connected well or not.
 - Check if the connectors are connected to correct position well or not.
- 3) Some causes of the balance problem
 - When the bottom of saddle or the groove of saddle is not flat.
 - When saddle is installed to the groove of saddle loosely.
 - When the connection is not good between the bottom of saddle and the groove of saddle.
 - When Saddle is very short
 - When there is grounds on the groove of saddle.
 - When Saddle is declined toward front or back.
 - When the top of guitar is bended.
 - When the pickup is installed to only a part of the groove of saddle.

Cutting Template

Print>Page Handling>Page Scaling

- None
- Fit to print margins
- Reduce to print margins

1. Print this file without scaling option.
2. Check the size with actual ruler.
3. Cut out the dotted line or desire model.
4. Adhere to location use double stick tape.
5. Cut follow solid line use cutter.

